

EQUALIZER • CINEMA SURROUND • COMPONENT INPUT

Contents

Knowing your TV's features 3
Remote control buttons and basic functions 4
TV buttons and functions 6
Setting up your TV 7
Basic setting for picture 9
Advanced setting for picture 11
Original features for picture 12
Basic setting for sound 14
Advanced setting for sound 15
Favorite channel and video setting 16
Customized setting 17
TV channel presetting 19
Additional preparation 22
Troubleshooting 23
Specifications ..... Back cover

INSTRUCTIONS

GGT0093-001A-H

21/04/2005, 7:37 PM

for buying this JVC colour television.
your new TV, please read this manual thoroughly before you begin.

**NOT
TURE.
THE
F THIS TV.**

f the TV.
lugging the

the TV of

chnician. Do

areful with it
d, wipe it
cleaner or

7 If you are not going to use this TV for a long period of time, be sure to disconnect the AC plug from the AC socket.
8 The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.

WARNING: <AV-2157YE/AV-2155YE only>
A REMOVABLE PLASTIC COVER IS FIXED TO THE TELEVISION'S FRONT AUDIO/VIDEO CONNECTOR. TO PREVENT THIS COVER FROM BEING ACCIDENTALLY SWALLOWED BY BABIES OR CHILDREN, REMOVE IT FROM THE TELEVISION AND STORE IT IN A SAFE PLACE. IF THE COVER IS SWALLOWED SEEK THE ADVICE OF A DOCTOR IMMEDIATELY.

es

ou can view two different sources (e.g. TV programme and VCR sources) at the same me.
ou can view teletext programmes which are broadcasted by some TV channels. Teletext rogramme is an information in text form.
ou can listen to the stereo sound or bilingual sound from TV programme broadcasting by A2 r NICAM Sound-multiplex system.
ou can register up to four favorite channels for quick recall with one press.
V detects the brightness of your room and automatically adjust the picture brightness to a uitable level for a better eye care.
V adjusts the volume automatically to the same level for all TV channels to avoid sudden hange of the volume when selecting different TV channel.

ons

this instruction manual may not be available for your TV.
w and check the functions that are equipped for your TV's model number. The l at the rear of your TV. When you press a button concerned to a function that is t does not work and the logo "Ø" appears on the screen. For a function that is t is not displayed in the menu.

	AV-29B7VE	AV-29S7WE	AV-21S7YE	AV-21S5YE
	○	○	–	–
	○	–	–	–
	○	○	–	–
	○	○	–	–

21/04/2005, 7:38 PM

nd basic functions

e.
ction.

olume.
o terminal number, stereo/bilingual broadcast system

R list.
splay the PR list.
se a channel, then press the MENU/OK button.
n the PR list. The channels set to favorite channels are

ton to return to the previous menu.
digits programme number, press -/--, then press the

l with one touch.
egister.
until “RETURN PLUS PROGRAMMED!” appears.
button until “RETURN PLUS CANCELED!” appears.
nnel, if you have not set or have cancelled the Return



continued)

	Top menu	2nd menu	Location	3rd menu	Location
MENU	INPUT	EXT. INPUT	P.18	–	–
		DISPLAY	P.18	–	–
	PICTURE * If you want to adjust PICTURE SETTING menu, you must set PICTURE MODE menu to USER.	PICTURE MODE	P.9	–	–
		PICTURE SETTING	P.10	–	–
		WHITE BALANCE	P.10	–	–
		PICTURE FEATURES	–	VNR	P.17
				FAVORITE CH SETTING	P.16
				VIDEO SETTING	P.16
				COLOUR SYSTEM	P.9
				COMPRESS (16:9)	P.11
				PICTURE TILT	P.11
	SOUND * If you want to adjust EQUALIZER menu, you must set SOUND MODE menu to USER.	STEREO/I•II	P.15	–	–
		AI VOLUME	P.15	–	–
		SOUND MODE	P.14	–	–
		EQUALIZER	P.15	–	–
		BALANCE	P.14	–	–
		SOUND TURBO	P.14	–	–
		CINEMA SURROUND	P.15	–	–
	FEATURES	OFF TIMER	P.17	–	–
		CHILD LOCK	P.17	–	–
		AI ECO SENSOR	P.11	–	–
		PIP	–	PIP,SUB INPUT,SWAP	P.12
	INSTALL	AUTO PROGRAM	P.19	–	–
		EDIT/MANUAL	P.19	DELETE, MOVE, MANUAL,INSERT	P.19-P.20
		LANGUAGE	P.17	LANGUAGE	P.17
		BLUE BACK	P.11	–	–
		AUTO SHUTOFF	P.18	–	–
		VIDEO-2 SETTING	P.18	–	–
		AI ECO DISPLAY	P.11	–	–
		TEXT LANGUAGE	P.13	TEXT LANGUAGE	P.13
	EXIT	–	–	–	–

Note

e MENU,
e DISPLAY/
utton* ❽ or
EXIT menu.

button ❸ to
he next page
functions.

–

e MENU/OK
❾ to exit from
u.

–

his manual,

cated in
ntrol.
ntrol.

21/04/2005, 7:38 PM

No.	Button/terminal	Description	Page
❶	⏻ (main power)	Press to turn on or turn off the TV's main power.	–
❷	POWER lamp	Indicate the TV is being turned on or off. No colour: TV's main power is being turned off. Red : TV's main power is being turned on. Note: When you turn off the power switch while TV is in standby mode, the light of power lamp will be off in 10 -15 seconds.	–
❸	ECO sensor		–
❹	Remote control sensor		–
❺	TV/ VIDEO	Press to select TV or video mode.	–
❻	VOLUME -/+	Press to adjust the volume level.	–
❼	CHANNEL -/+	Press to select the desired channel.	–
❽	MENU	Press to display the menu.	–
❾	IN (VIDEO-3)	Video and audio input jacks for VIDEO-3 mode.	22
	IN (VIDEO-2)	Video and audio input jacks for VIDEO-2 mode.	22
❿	🎧	Headphone jack.	22
⓫	⊤	Aerial socket.	7
⓬	OUTPUT	Video and audio output jacks. (The component video signal cannot be output.)	22
⓭	COMPONENT (VIDEO-2) INPUT	Video or component video, and audio input jacks for VIDEO-2 mode. You can select the input signal by setting the "VIDEO-2 SETTING" function (see page 18).	22
⓮	VIDEO-1 INPUT	Video or S-VIDEO, and audio input jacks for VIDEO-1 mode	7
⓯	TIMER lamp	Indicate the OFF TIMER function is being turned on or off. No colour: The OFF TIMER function is being turned off. Orange : The OFF TIMER function is being turned on.	–

How to operate the menus with the TV button

TV button	Work as same as the button on the remote control unit	Note
MENU	MENU/OK button	To display main menu and exit menu after finish setting.
CHANNEL -/+	▼/▲ button	To select menu function.
VOLUME -/+	◄/► button	To adjust the desired function.

ecting.

aerial

plied)

our VCR
connect the
the TV
audio

erial

e as your

2 Connecting the compatible main plug to the AC outlet.



3 Inserting batteries into the remote control.

Insert two batteries by following the ⊕ and ⊖ polarities and inserting the ⊖ end first.

CAUTION:

Follow the cautions printed on the batteries.

Notes:

- Use AA/R6/UM-3 dry cell batteries.
- It the remote control does not work properly, fit new batteries. The supplied batteries are for testing, not regular use.



4 Turn on the TV by pressing the main power button.

JVC logo appears on the screen.

21/04/2005, 7:38 PM

or 15 seconds, then operate the TV by following the steps as below:



- TV will start searching for the channels.

  To stop AUTO PROGRAM, press MENU/OK button.



- Press the red button to cancel the SETUP TOUR RESTART function.
  If you want to make initial settings again when the next time you turn on the TV, press the MENU/OK button to activate the SETUP TOUR RESTART function.



- To complete the initial setting, press the MENU/OK button. To edit the channel list, see page 19.

XT LANGUAGE, and AUTO PROGRAM functions to make the initial settings.

tial settings, press the TV/VIDEO button to exit from initial settings.

picture is

.

S menu

e table

	System
,	PAL
	PAL
	PAL
	SECAM
	NTSC
	SECAM
	PAL
	PAL
	PAL
	PAL
	PAL
	PAL
	SECAM

PICTURE MODE

You can choose the desired picture setting with one-touch. Press the PICTURE MODE button to select a setting.

SOFT	Softens contrast and sharpness.
BRIGHT	Heightens contrast and sharpness.
STANDARD	Standard picture setting.
USER	You can change this picture setting as you like. Select USER and adjust following items in the PICTURE SETTING menu. (CONTRAST, BRIGHT, SHARP, COLOUR, TINT*)

*TINT can only be adjusted in NTSC system.

To operate this function with a menu:

✳ (MENU) ➡ (PICTURE menu) ➡ (PICTURE MODE)

To return the USER setting to the default, press the blue button when the PICTURE SETTING menu appears.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:38 PM

WHITE BALANCE

You can change the white balance of the picture to better match the type of video being viewed.
Select the WHITE BALANCE in the PICTURE menu, then choose the desired setting.

✳ (MENU) ➔ (PICTURE menu) ➔ (WHITE BALANCE)

NORMAL	Normal white balance.
COOL	Bluish white.
WARM	Reddish white.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

ghtness of

R)

e screen.
n choose

E TILT)

netic force.
ES menu
.
RES menu)

2 Press the ▲/▼ buttons until the picture become level. Then press the MENU/OK button.

COMPRESS (16:9)

You can convert a normal picture (4:3 aspect ratio) into a wide picture (16:9 aspect ratio).
Select the COMPRESS (16:9) in the PICTURE FEATURES menu under PICTURE menu, then choose ON or OFF.

✳(MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (COMPRESS (16:9))

BLUE BACK

You can set the TV to automatically change to a blue screen and mute the sound if the signal is weak or absent, or when there is no input from an antenna.

Select the BLUE BACK in the INSTALL menu, then choose ON or OFF.

✳(MENU) ➔ (INSTALL menu) ➔ (BLUE BACK)

If you wish to continue viewing the poor picture, cancel the BLUE BACK function.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:38 PM

When VIDEO-2 is set to component, if the input source of main picture is set to VIDEO-2 with component, PIP button is disabled and sub picture can't be displayed.

TELETEXT

You can watch the Teletext broadcast channel with TEXT function.

1 Press the TEXT button to select the desired mode as follows:

TV mode → TEXT mode → MIX mode

2 Press the CHANNEL -/+ buttons, number buttons or colour buttons to select other Teletext pages.

3 Press TEXT or TV/VIDEO button to return to TV mode.

You can also operate the teletext using the following buttons:

(Hold)	Hold a teletext page. The (hold) are displayed at the top left of the screen. To cancel, press (Hold) button again.
(Reveal)	Display the hidden text (e.g. answers to a quiz). To cancel, press (Reveal) button again.
(Size)	Enlarge the teletext display.
(Index)	Return to the index page instantly.
(Cancel)	Watch TV programme while waiting for a teletext page. When the teletext page is found, a page number appears at the upper left of the screen. Press (Cancel) to view the teletext page.
(Sub-page)	Operate the (Sub-page) function. Sub-page numbers are displayed at the left of the screen. To cancel sub-page function, press (Sub-page) button again.

✳ About the basic operations of the menu, please see the "How to operate menus and menus locations" on page 5.

TEXT LANGUAGE

You can set the Teletext language group that corresponds to the programmes.
Select TEXT LANGUAGE in the INSTALL menu, then choose the desired language group.

✳ (MENU) ➔ (INSTALL menu) ➔ (TEXT LANGUAGE)

GROUP-1	English, German, Swedish / Finnish / Danish / Hungarian, Italian, French, Spanish / Portuguese, Turkish
GROUP-2	Polish, German, Estonian, Slovenian, Czech / Slovakian, Rumanian
GROUP-3	Polish, German, Estonian, Lettish, Russian, Ukrainian

Depending on the broadcast, the language set may not display properly.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:39 PM

ormal

e table

	System
	B/G
	D/K
	I
	B/G
	M
	D/K
	D/K
	B/G
	I
	B/G
	I
	B/G
	B/G

SOUND MODE

You can choose the desired sound setting.
Select the SOUND MODE in SOUND menu, then choose the setting.

✳ (MENU) ➡ (SOUND menu) ➡ (SOUND MODE)

USER	You can change this sound setting as you like. Select USER and adjust the frequencies in EQUALIZER (100, 300, 1K, 3K, 8K Hz). For details, see “EQUALIZER” on page 15.
DYNAMIC	Emphasize on both vocal sound and music.
MUSIC	Emphasize on music effect.
NEWS	Emphasize on vocal sound.

BALANCE

You can adjust the volume balance between the left and right speakers.
Select the BALANCE in SOUND menu, then adjust the setting.

✳ (MENU) ➡ (SOUND menu) ➡ (BALANCE)

SOUND TURBO

You can enjoy the emphatic low and high frequency levels.

Press the SOUND TURBO to select ON or OFF.
To operate this function with a menu:

✳ (MENU) ➡ (SOUND menu) ➡ (SOUND TURBO)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

nd

ng.

nce effect.
ce effect.
t.

ID)

l mode,
OUND

together,

grammes.

the sound

EQUALIZER

You can adjust the sound level of each frequencies when selecting USER mode in SOUND MODE.

1 Select the USER in SOUND MODE under SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (SOUND MODE) ➔ (USER)

2 Select the EQUALIZER in SOUND menu.
✳ (MENU) ➔ (SOUND menu) ➔ (EQUALIZER)

The following display appears.



3 Select and adjust the desired frequencies.

4 Press the MENU/OK button to exit the menu.

Adjust high frequency will affect higher pitch sound and vice versa.

AI VOLUME

You can adjust the volume of all the channels and video inputs to the same level automatically.
Select the AI VOLUME in SOUND menu, then choose ON or OFF.

✳ (MENU) ➔ (SOUND menu) ➔ (AI VOLUME)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:39 PM

eo setting

4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

To adjust the video setting (VIDEO SETTING)

You can adjust the picture and sound settings for video inputs.

1 Display the PICTURE menu and select VIDEO SETTING in PICTURE FEATURES menu.
✳(MENU) ➔ (PICTURE menu) ➔ (PICTURE FEATURES menu) ➔ (VIDEO SETTING)

2 Select VIDEO STATUS in VIDEO SETTING menu, then choose the desired video input.
✳(VIDEO SETTING) ➔ (VIDEO STATUS)

3 Select EFFECT, then press ◄/► button to choose ON.
To cancel the settings, choose OFF.



4 Select the desired item that you wish to adjust.
CONTRAST ↔ BRIGHT ↔ SHARP ↔ COLOUR
SOUND MODE (USER, DYNAMIC, MUSIC, NEWS) ↔ TINT

5 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

CHILD LOCK

You can disable the front control buttons of the TV.
Select the CHILD LOCK in the FEATURES menu, then choose ON or OFF.

✳ (MENU) ➡ (FEATURES menu) ➡ (CHILD LOCK)

OFF TIMER

You can set the TV to turn off automatically to standby mode after a set time.
Press the OFF TIMER button to select a desired period of time.



You can set the period of time to a maximum of 120 minutes in 10 minutes step.

To operate this function with a menu:

✳ (MENU) ➡ (FEATURES menu) ➡ (OFF TIMER)

When the elapsed of time left one minute, “GOOD NIGHT!” appears on the screen.
You can display the OFF TIMER menu again to confirm or change the remaining time.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:39 PM

EXT. INPUT (TV/VIDEO)

You can select TV or video terminal input with one touch.
Press the TV/VIDEO button to select an input.
To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (EXT. INPUT)

DISPLAY

You can display the programme number, video terminal number and PR list on the screen.
Press the DISPLAY button to select the desired mode:

ON → OFF → PR LIST

Choose a TV channel or a VIDEO terminal.

1 Press the DISPLAY button to display the PR LIST.

2 Select a programme number or video terminal by pressing the ▲/▼ button to move up/down on the programme number or press the ◄/► button to skip for each 7 programme numbers, then press MENU/OK button.



To operate this function with a menu:

✳ (MENU) ➡ (INPUT menu) ➡ (DISPLAY)

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.



3 Choose the channel which you want to register.

4 Press the blue button to activate the MANUAL function.
The sound system of the channel appears at the right of the CH/CC number.

5 Press the ► button to choose an appropriate sound system.
For details, see “SOUND SYSTEM” on page 14.

6 Press the green or red button to search for the TV channel.
Searching stops when a channel is found and displayed.

7 Repeat step 5 until your desired TV channel appears

If the reception is poor	Press the blue or yellow button to fine tune the TV channel.
If noisy sound is heard	Press the ► button to choose an appropriate sound system.

8 Press the MENU/OK button to exit the menu.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

21/04/2005, 7:39 PM

To add in the new channel (INSERT in the EDIT menu)

You can add in the new channel in the TV channel list as you like. You need to find the “CH/CC” number for the TV channel. Find the “CH/CC” number corresponding to the channel number of the TV channel from the attached sheet “CH/CC number list” on page 21.

1 Display the INSTALL menu.
✳ (MENU) ➡ (INSTALL menu)

2 Choose EDIT/MANUAL, then press the MENU/OK button.
EDIT menu appears.

3 Choose the PR number for which you will register a new TV channel. When you add a new TV channel of NTSC-M system, press the SOUND SYSTEM button to change the sound system to M. Then proceed to the next step.

4 Press the green button, then press ▲/▼ buttons to choose “CC” or “CH”.

5 Press the number button to enter the remaining CH/CC number.
The TV starts to search the TV channel, and the picture of the TV channel appears. If the TV finds no TV channel, a noisy picture appears.

When a TV channel has already been registered in PR99, using the INSERT function deletes that TV channel.

✳ About the basic operations of the menu, please see the “How to operate menus and menus locations” on page 5.

US	CCIR	OIRT	AUSTRALIA
S-33, W+48	E33		
S-34, W+49	E34		
S-35, W+50	E35		
S-36, W+51	E36		
S-37, W+52	E37		
S-38, W+53	E38		
S-39, W+54	E39		
S-40, W+55	E40		
S-41, W+56	E41		
S-42, W+57	E42		
S-43, W+58	E43		
S-44, W+59	E44		
S-45, W+60	E45		
S-46, W+61	E46		
S-47, W+62	E47		
S-48, W+63	E48		
S-49, W+64	E49		
S-50, W+65	E50		
S-51, W+66	E51		
S-52, W+67	E52		
S-53, W+68	E53		
S-54, W+69	E54		
S-55, W+70	E55		
S-56, W+71	E56		
S-57, W+72	E57		
S-58, W+73	E58		
S-59, W+74	E59		
S-60, W+75	E60		
S-61, W+76	E61		
S-62, W+77	E62		
S-63, W+78	E63		
S-64, W+79	E64		
S-65, W+80	E65		
S-66, W+81	E66		
S-67, W+82	E67		
S-68, W+83	E68		
S-69, W+84	E69		

US	CCIR	OIRT	AUSTRALIA
	S-1		AU-5
	S-2		
	S-3		
	S-4		
	S-5		
	S-6		AU-5A
	S-7		
	S-8		
	S-9		
	S-10		
	S-11		
	S-12		
	S-13		
A	S-14		
B	S-15		
C	S-16		
D	S-17		

CC	US	CCIR	OIRT	AUSTRALIA
CC 18	E	S-18		
CC 19	F	S-19		
CC 20	G	S-20		
CC 21	H	S-21		
CC 22	I	S-22		
CC 23	J	S-23		
CC 24	K	S-24		
CC 25	L	S-25		
CC 26	M	S-26		
CC 27	N	S-27		
CC 28	O	S-28		
CC 29	P	S-29		
CC 30	Q	S-30		
CC 31	R	S-31		
CC 32	S	S-32		
CC 33	T	S-33		
CC 34	U	S-34		
CC 35	V	S-35		
CC 36	W	S-36		
CC 37	W+1	S-37		
CC 38	W+2	S-38		
CC 39	W+3	S-39		
CC 40	W+4	S-40		
CC 41	W+5	S-41		
CC 42	W+6			
CC 43	W+7			
CC 44	W+8			
CC 45	W+9			
CC 46	W+10			
CC 47	W+11			
CC 48	W+12			
CC 49	W+13			
CC 50	W+14			
CC 51	W+15			
CC 52	W+16			
CC 53	W+17			
CC 54	W+18			
CC 55	W+19			
CC 56	W+20			
CC 57	W+21			
CC 58	W+22			
CC 59	W+23			
CC 60	W+24			
CC 61	W+25			
CC 62	W+26			
CC 63	W+27			
CC 64	W+28			
CC 75		X		
CC 76		Y	R3	
CC 77		Z	R4	AU-3
CC 78		Z+1	R5	
CC 79		Z+2		AU-4
CC 95	A-5			
CC 96	A-4			
CC 97	A-3			
CC 98	A-2			
CC 99	A-1			

21/04/2005, 7:39 PM

E and
se. Your

proper

al

TV game

Connecting to rear component/video input terminal and output terminal

Rear of TV

AV-2987VE



VCR (for playing)
DVD player (composite signals)

VCR (for recording)

DVD player
(component video signals)

Rear of TV

AV-2157YE



VCR (for playing)
DVD player (composite signals)

VCR (for recording)

When you use VIDEO-1 INPUT, you should choose to connect S-VIDEO or video input. If S-VIDEO connector and video input are connected at the same time, no picture display on the screen and the message “PLEASE DISCONNECT VIDEO-1 CABLE!” appears. In this case, you should disconnect either S-VIDEO or video input.

When connecting to COMPONENT (VIDEO-2) input, depending on the connection, choose the appropriate video input using the menu (see page 18).

• Cannot operate the remote control	• The batteries may be exhausted. Replace with new batteries (see page 7). • Ensure that you are operating the remote less than seven meters from the front of your TV.
• Cannot operate the menus	• Press TV/VIDEO button to return to TV mode and try operating the menus.
• Cannot operate the front control buttons	• Deactivate the CHILD LOCK function if it is turned on (see page 17).
• TV is turned off suddenly	• This may due to the AUTO SHUTOFF function is activated. Press the POWER button to turn on the TV.
• Colour patches appear at the corner of the screen	• This may due to the magnetized device such as a speaker near to your TV. Keep the device apart from your TV. Alternately, you can also use the magnetic-shielded speaker.
• Picture is tilted	• This may due to the earth magnetism. Refer to “PICTURE TILT” on page 11 to correct the tilt.
• Image takes a short period to be displayed	• Image required time to stabilize before display. This is not a malfunction.
• TV may emitted crackling sound	• This is due to a sudden change in temperature and it is not a malfunction. If the crackling sound is too frequent, request your service technician for inspection.
• Feel a slight electric shock when touching the TV screen	• This is due to the static electricity of the picture tube and it will not harm the human body. This is not a malfunction.

21/04/2005, 7:39 PM

z

UHF channel (U)
nd and hyper band.

O input, AUDIO L/R input
L/R input, COMPONENT VIDEO (Y/C_B/C_R) input (Except for AV-2157YE/

L/R input (Except for AV-2157YE/AV-2155YE.)
O L/R output
mm diameter)

ANGUAGE" on page 13.
Sound-multiplex systems may not be available. Please confirm with the chart

ut notice.

JVC